

PRODUCT DETAILS				
NAME	The Therapist™	SIZE: 1L	BARCODE	9356532010293
PRODUCT OVERVIEW AND USES				
<p>Lustre FX® The Therapist™ is an impregnating invisible sealer for interior and exterior that protects damage caused by water and oil based stains. It can be used on any of Lustre FX® range of venetian plasters, concrete finishes or metallic coatings to provide lasting protection and ease of cleaning. Suitable for concrete bench tops, floors, walls, swimming pool surrounds, kitchens and entertaining areas. The Therapist™ allows the substrate to breathe, as it is water vapour permeable as it deeply penetrates to protect against weathering and wearing.</p>				
TYPICAL SYSTEM				
Coats	Product	Theoretical Spread rate (m <sup>2</sup> /L)	Dry time (mins)	Recoat time (min)
1 <sup>st</sup> Coat	The Therapist™	2-25 m <sup>2</sup> /L	10-15	15
2 <sup>nd</sup> Coat	The Therapist™	2-25m <sup>2</sup> /L	10-15	
TYPICAL PROPERTIES				
V.O.C LEVEL	<50g/L	CLEAN UP	Methylated Spirits	
APPLICATION METHOD	Brush, Roller, airless sprayer, lambs wool roller, cloth for high polished surfaces			
COVERAGE YIELDS	2-25 m <sup>2</sup> /L depending on porosity of surface to be coated.			
APPLICATION + MIXING GUIDE				
<p><b>We advise a small test area, prior to use on the full surface to observe drying time and coverage of the material. For optimal application 5-35°C away from direct sunlight.</b></p>				
<p><b>Surface Preparation</b></p> <ul style="list-style-type: none"> <li>• Surface must be free of any oil, dirt, waxes and any other contaminants.</li> <li>• <b>DO NOT THIN The Therapist™</b></li> <li>• <b>IF THE SUBSTRATE IS HIGHLY POROUS, PRE-SEAL IT WITH A LIGHT SPRAY OF THE THERAPIST™ BEFORE APPLYING THE TWO MAIN COATS.</b></li> </ul>				
<p><b>Application</b></p> <ul style="list-style-type: none"> <li>• Generously apply to the surface by brush, roller or an airless sprayer. If the surface is highly polished use a lambs wool applicator or pad. Then surface should have a mirror like wet look for 3-5 seconds.</li> <li>• Apply another coat after the first coat is touch-dry (10 – 15 minutes) as per above.</li> <li>• After 15 minutes polish the surface with a, clean lint free white cloth to remove any excess product.</li> <li>• After 24 hours the product is cured and is food contact safe.</li> </ul>				
PRECAUTIONS AND LIMITATIONS				
<ul style="list-style-type: none"> <li>• Prior to application ensure that the substrate is dry, clean and free from contaminants such as oil, grease, mould and fungus.</li> <li>• Apply in temperatures between 5-35°C. Applying in temperatures below 5°C or over 85% relative humidity, will vary curing rates.</li> <li>• Do not apply in the presence of strong wind, sunlight or when rain is imminent.</li> <li>• <b>Coverage rates will depend on the absorption of the porosity of the surface material being</b></li> </ul>				

treated.

- For polished surfaces we recommend a lamb's wool roller or cloth so The Therapist™ is wiped over the surface, **SPRAYING IS NOT RECOMMENDED FOR POLISHED SURFACES.**
- After 24 hours the product is cured, however the full benefits of The Therapist™ happen about 3-4 weeks after application, as the molecules bond deeper inside the pores of the surface.
- The Therapist™ will not prevent surface etching, scuff marks or wear and may lighten or darken some surfaces (hence it is recommended to test a small patch first applying)
- Lustre FX® recommends its products are applied by tradespeople with experience in the application of concrete or rendering products, or by artisans that have attended The Alchemy Academy® to ensure finishes are similar to samples specified.

HEALTH AND SAFETY	
SDS (Safety Data Sheet) NUMBER	<b>LFX0027</b>
SDS LINK	Go to <a href="http://www.lustrefx.com.au">www.lustrefx.com.au</a> to Download Safety Data Sheet
SAFETY PRECAUTIONS	
Causes serious eye irritation. Causes skin irritation. May cause damage to organs through prolonged or repeated exposure. Keep out of reach of children. Read label before use. Avoid breathing vapour. Wear protective clothing, gloves, eye/face protection and suitable dust mask/respirator as required. Wash contaminated clothing before re-use. Wash hands, face and all exposed skin thoroughly after handling. Store in a well-ventilated area away from oxidising agents, acids and foodstuffs. Do not empty into drains.	
HEALTH EFFECTS	<b>IN CASE OF EMERGENCY PLEASE CALL 1800 033 111 if medical advice is needed, have product container or label at hand.</b>
<p><b>SWALLOWED:</b> If swallowed, do NOT induce vomiting. Give a glass of water to drink. Never give anything by mouth to an unconscious patient. Seek medical advice.</p> <p><b>EYE:</b> If in eyes, hold eyes open, flood with water for at least 15 minutes and see a doctor.</p> <p><b>SKIN:</b> If skin contact occurs, remove contaminated clothing and wash skin thoroughly. Continue flushing with water and if irritation occurs seek medical advice.</p> <p><b>INHALED:</b> Remove patient from contaminated area. Remove contaminated clothing. Apply artificial respiration if not breathing. Seek medical advice.</p>	
TRANSPORT AND STORAGE	
Store out of direct sunlight in a cool dry area. The Therapist™ product should maintain its properties for 12 months if stored from excessive heat and cold temperatures.	
DISPOSAL	<b>DO NOT</b> pour down drains, refer to local regulations for the disposal of water-based waste. Recycle empty containers in accordance with current regulations.

#### DISCLAIMER

The data provided within this PRODUCT DATA SHEET ("PDS") is correct at the time of publication, however it is the responsibility of the applicator using this information to check that it is current prior to specifying or using any of these coating systems.

Lustre FX®, Lustre-Crete®, and any other marks followed by ® are registered trademarks of Lustre FX Pty Ltd ACN 638 855 704 ABN 82 638 855 704 ("LFX"). Marks followed by the symbol of ™ are trademarks.

Any advice, recommendation, information, assistance, training or service provided by LFX or its related entities in relation to goods manufactured by it or their use and application is given in good faith and believed by LFX and its related entities to be appropriate and reliable. However any advice, recommendation, information, assistance, training or service provided by LFX or its related entities is provided without liability or responsibility, provided that the foregoing shall not exclude, limit, restrict or modify the rights entitlements and remedies conferred upon any person, or the liabilities imposed upon LFX or its related entities, by any condition or warranty implied by any applicable legislation which cannot be excluded, limited or modified. Coating and product systems can be expected to perform as indicated on the PDS so long as applications and application procedures of the individual products are followed as recommended on the appropriate PDS by a qualified trained and experienced professional. The full terms and conditions of the warranty provided by LFX and its related entities (and exclusions of liability) can be downloaded at: [www.lustrefx.com.au](http://www.lustrefx.com.au) OR The full terms and conditions of the warranty provided by LFX and its related entities can be obtained by attending the office of LFX at 6 Nick Ellis Place Hume, ACT, 2620, Australia.